

## INFORMATION

### Distinction of products made from smooth cardboard:

#### RECY


- standard quality from recycled material, (100% compostable and 100% recyclable)  
designed for DRY and NON-GREASY food.

#### PAP - Virgin

- 100% compostable and 100% recyclable material, suitable for all types of food.

## REPLACED ARTICLES



**Paper tray**  
(PAP) 7 x 14 cm  
**71118**  12 x 250 pcs  
**sold out**




**Paper tray**  
(PAP - Virgin) 7 x 14 cm  
**71101**  12 x 250 pcs

## RECY

### RECY

### PAP - Virgin




**Paper tray RECY**  
(PAP) 10 x 16 cm  
**71120**  8 x 250 pcs




**Paper tray**  
(PAP - Virgin) 7 x 14 cm  
**71101**  12 x 250 pcs *New*




**Paper tray RECY**  
(PAP) 13 x 20 cm  
**71122**  4 x 250 pcs




**Paper tray**  
(PAP - Virgin) 13 x 20 cm  
**71104**  4 x 250 pcs




**Paper tray RECY**  
(PAP) 16 x 20 cm  
**71123**  4 x 250 pcs




**Paper tray**  
(PAP - Virgin) 16,5 x 20 cm  
**71105**  4 x 250 pcs *New*




**Paper tray RECY**  
(PAP) 16 x 23 cm  
**71124**  4 x 250 pcs




**Paper tray**  
(PAP - Virgin) 16 x 23 cm  
**71106**  4 x 250 pcs




**Paper tray RECY**  
(PAP) 17 x 25 cm  
**71126**  2 x 250 pcs




**Paper tray**  
(PAP - Virgin) 17,5 x 25 cm  
**71107**  4 x 250 pcs *New*




**Paper tray RECY**  
(PAP) 21 x 29 cm  
**71127**  2 x 125 pcs




**Paper tray**  
(PAP - Virgin) 21 x 30 cm  
**71108**  2 x 125 pcs *New*




**Paper tray RECY**  
(PAP) 19 x 33,5 cm  
**71128**  2 x 125 pcs




**Paper tray**  
(PAP - Virgin) 19 x 33 cm  
**71109**  2 x 125 pcs *New*



**Paper tray RECY**  
(PAP) 23 x 33 cm  
**71129**  2 x 125 pcs



**Paper tray**  
(PAP - Virgin) 23 x 33 cm  
**71110**  2 x 125 pcs *New*



## RECY



**Paper tray RECY**  
(PAP) 11 x 17 cm  
71143 20 x 100 pcs



**Paper tray RECY**  
(PAP) 13 x 20 cm  
71144 10 x 100 pcs



**Paper tray RECY**  
(PAP) 16 x 23 cm  
71145 10 x 100 pcs



**Paper tray RECY**  
(PAP) 17 x 25 cm  
71146 5 x 100 pcs

## PAP - Virgin



**Paper tray**  
(PAP - Virgin) 11 x 17 cm  
71103 8 x 250 pcs



**Paper tray**  
(PAP - Virgin) 13 x 20 cm  
71104 4 x 250 pcs



**Paper tray**  
(PAP - Virgin) 16 x 23 cm  
71106 4 x 250 pcs



**Paper tray**  
(PAP - Virgin) 17,5 x 25 cm  
71107 4 x 250 pcs

*New*

## RECY



**Cardboard cake base RECY**  
(PAP) Ø 18 cm  
71618 5 x 100 pcs



**Cardboard cake base RECY**  
(PAP) Ø 20 cm  
71620 5 x 100 pcs



**Cardboard cake base RECY**  
(PAP) Ø 22 cm  
71622 5 x 100 pcs



**Cardboard cake base RECY**  
(PAP) Ø 24 cm  
71624 5 x 100 pcs



**Cardboard cake base RECY**  
(PAP) Ø 26 cm  
71626 5 x 100 pcs



**Cardboard cake base RECY**  
(PAP) Ø 28 cm  
71628 5 x 100 pcs



**Cardboard cake base RECY**  
(PAP) Ø 30 cm  
71630 5 x 100 pcs



**Cardboard cake base RECY**  
(PAP) Ø 32 cm  
71632 5 x 100 pcs

## PAP - Virgin



**Cardboard cake base**  
(PAP - Virgin) Ø 18 cm  
71318 5 x 100 pcs

*New*



**Cardboard cake base**  
(PAP - Virgin) Ø 20 cm  
71320 5 x 100 pcs

*New*



**Cardboard cake base**  
(PAP - Virgin) Ø 22 cm  
71322 5 x 100 pcs

*New*



**Cardboard cake base**  
(PAP - Virgin) Ø 25 cm  
71325 5 x 100 pcs

*New*



**Cardboard cake base**  
(PAP - Virgin) Ø 26 cm  
71326 5 x 100 pcs

*New*



**Cardboard cake base**  
(PAP - Virgin) Ø 28 cm  
71328 5 x 100 pcs

*New*



**Cardboard cake base**  
(PAP - Virgin) Ø 30 cm  
71330 5 x 100 pcs

*New*



**Cardboard cake base**  
(PAP - Virgin) Ø 32 cm  
71332 5 x 100 pcs

*New*

## RECY



**Paper plate round RECY**  
(PAP - Recycled) Ø 15 cm  
71415 12 x 100 pcs



**Paper plate round RECY**  
(PAP) Ø 18 cm  
71418 5 x 100 pcs



**Paper plate round RECY**  
(PAP) Ø 23 cm  
71423 5 x 100 pcs

## PAP - Virgin



**Paper plate round**  
(PAP - Virgin) Ø 15 cm  
71215 12 x 100 pcs

*New*



**Paper plate round**  
(PAP - Virgin) Ø 18 cm  
71218 10 x 100 pcs

*New*



**Paper plate round**  
(PAP - Virgin) Ø 23 cm  
71223 5 x 100 pcs

*New*



## RECY

## PAP - Virgin



**Deep paper plate round RECY**  
(PAP) Ø 26 cm  
**71426** 5 x 50 pcs



**Deep paper plate round RECY**  
(PAP) Ø 29 cm  
**71429** 5 x 50 pcs



**Deep paper plate round RECY**  
(PAP) Ø 32 cm  
**71432** 4 x 50 pcs



**Deep paper plate round RECY**  
(PAP) Ø 34 cm  
**71434** 4 x 50 pcs



**Deep paper plate round**  
(PAP - Virgin) Ø 24 cm  
**71224** 4 x 50 pcs

*New*



**Deep paper plate round**  
(PAP - Virgin) Ø 26 cm  
**71226** 5 x 50 pcs

*New*



**Deep paper plate round**  
(PAP - Virgin) Ø 28 cm  
**71228** 4 x 50 pcs

*New*



**Deep paper plate round**  
(PAP - Virgin) Ø 30 cm  
**71230** 4 x 50 pcs

*New*



**Deep paper plate round**  
(PAP - Virgin) Ø 32 cm  
**71232** 4 x 50 pcs

*New*



**Deep paper plate round**  
(PAP - Virgin) Ø 34 cm  
**71234** 4 x 50 pcs

*New*

## RECY



**Cardboard cake box with handle**  
(PAP) 27 x 18 x 8 cm  
**71708** 1 x 50 pcs



**Cardboard cake box with handle**  
(PAP) 27 x 18 x 10 cm  
**71710** 1 x 50 pcs



**Cardboard cake box**  
(PAP) 18 x 18 x 9 cm  
**71718** 1 x 50 pcs



**Cardboard cake box**  
(PAP) 20 x 20 x 10 cm  
**71720** 1 x 50 pcs



**Cardboard cake box**  
(PAP) 22 x 22 x 9 cm  
**71722** 1 x 50 pcs



**Cardboard cake box**  
(PAP) 25 x 25 x 10 cm  
**71725** 1 x 50 pcs



**Cardboard cake box**  
(PAP) 28 x 28 x 10 cm  
**71728** 1 x 50 pcs




**Cardboard cake box**  
(PAP) 30 x 30 x 10 cm  
**71730** 1 x 50 pcs



**Cardboard cake box**  
(PAP) 32 x 32 x 10 cm  
**71732** 1 x 50 pcs



**Cardboard cake box, rectangular**  
(PAP) 30 x 45 x 10 cm  
**71745** 1 x 50 pcs



For use with greasy products,  
we recommend using in combination  
with sheets **90012 - 90050**.